



CAREFULLY REMOVE PROTECTIVE PLASTIC COVERING FROM THE FRONT OF THE DUO.

Buttons Layout (on back panel)

SET (Setting Mode)

- ▲ Time adjust +
- ▼ Time adjust -

Setting Steps

- Insert AC adapter into back of clock and plug electric cord into wall outlet.
- Press and hold SET button for 5 seconds until white hour numbers flash.
- Change hour time using ▲ and ▼ buttons.
- Press SET button briefly until <u>red</u> minute numbers flash.
- Change **minute** time using ▲ and ▼ buttons. (For most accurate time, set minute to *one minute* <u>past</u> current minute before proceeding to next step.)
- Press SET button when desired minute is as close as possible to zero seconds. Then white month numbers will flash.
- Change month using ▲ and ▼ buttons. Note: Month 1 is January; Month 12 is December.
- Press SET button briefly until red day of month numbers flash.
- Change day of month using ▲ and ▼ buttons.
- Press SET button briefly until <u>red</u> year numbers flash.
- Change year using ▲ and ▼ buttons. Note: "24" is 2024.
- Press and hold SET button for 5 seconds. Clock/Calendar will stop flashing and will save all settings.
- Date and time will toggle every 5 seconds. Press ▲ to display date only; Press ▼ to display time only. To display date & time toggle, unplug and replug power cord.
- Built-in battery backup will retain all settings if there is a power failure or Duo is unplugged and moved to a
 different location.

Need help? Email info@innOHvations.com