

A NEW WAY TO LOOK AT TIME


Diamond Duo™
Clock+Calendar

by innOHvations.com

Hours/Months in white

Minutes/Days in red

AM/PM in green



CAREFULLY REMOVE PROTECTIVE PLASTIC COVERING FROM THE FRONT OF THE DUO.

Buttons Layout (on back panel)

SET (Setting Mode)

- ▲ Time adjust +
- ▼ Time adjust -

Setting Steps

- Insert AC adapter into back of clock and plug electric cord into wall outlet.
- Press and hold SET button for 5 seconds until white hour numbers flash.
- Change **hour** time using ▲ and ▼ buttons.
- Press SET button briefly until red minute numbers flash.
- Change **minute** time using ▲ and ▼ buttons. (For most accurate time, set minute to *one minute past* current minute before proceeding to next step.)
- Press SET button when desired minute is as close as possible to zero seconds. Then white month numbers will flash.
- Change **month** using ▲ and ▼ buttons. Note: Month 1 is January; Month 12 is December.
- Press SET button briefly until red day of month numbers flash.
- Change **day of month** using ▲ and ▼ buttons.
- Press SET button briefly until red year numbers flash.
- Change **year** using ▲ and ▼ buttons. Note: "24" is 2024.
- Press and hold SET button for 5 seconds. Clock/Calendar will stop flashing and will save all settings.
- **Date** and **time** will toggle every 5 seconds. Press ▲ to display **date** only; Press ▼ to display **time** only. To display date & time toggle, unplug and replug power cor
- Press SET button once to turn hourly clock chime on/off.
- Built-in battery backup will retain all settings if there is a power failure or Duo is unplugged and moved to a different location.

Need help? Email info@innOHvations.com