

A NEW WAY TO LOOK AT TIME


# Crossword Calendar™

by innOHvations.com

Month in red

Day of week in green

Date in white



**CAREFULLY REMOVE PROTECTIVE PLASTIC COVERING FROM THE FRONT OF THE CALENDAR.**

## Buttons Layout (on back panel)

SET (Setting Mode)

- ▲ Time adjust +
- ▼ Time adjust -
- ▲ Brightness adjust

## Setting Steps

- Insert AC adapter into back of calendar and plug electric cord into wall outlet.
- Press and hold SET button for 3 seconds until **year** numbers flash ("22" for 2022).
- Change **year** using ▲ and ▼ buttons.
- Press SET briefly until **month** letters flash.
- Change **month** using ▲ and ▼ buttons.
- Press SET briefly until **date** numbers flash.
- Change **date** using ▲ and ▼ buttons.
- Press SET briefly until **hour** numbers flash. (NOTE: Setting **current hour** is necessary for calendar to advance to next date near midnight.)
- Change **hour** using ▲ and ▼ buttons using 24 hour clock (e.g., 12:00pm noon is 12; 1:00pm is 13; 11:00pm is 23; 12:00am midnight is 00).
- Press SET briefly until **day of week** letters flash.
- Change **day of week** using ▲ and ▼ buttons.
- Press and hold SET button for 3 seconds.
- Calendar will stop flashing and will save settings.
- Press ▲ button to cycle through 5 brightness settings until reaching desired brightness.
- Built-in battery backup will retain all settings if there is a power failure or calendar is unplugged and moved to a different location.

**Need help? Email [info@innOHvations.com](mailto:info@innOHvations.com)**