

A NEW WAY TO LOOK AT TIME



by innOHvations.com

Hours in white

Minutes in red

AM/PM in green



CAREFULLY REMOVE PROTECTIVE PLASTIC COVERING FROM THE FRONT OF THE CLOCK.

Buttons Layout (on back panel)

SET (Setting Mode)

- ▲ Time adjust +
- ▼ Time adjust -
- ▲ Brightness adjust

Setting Steps

- Insert AC adapter into back of clock and plug electric cord into wall outlet.
- Press and hold SET button for 3 seconds until white hour letters flash.
- Change hour and AM/PM time using ▲ and ▼ buttons.
- Press SET briefly until red minute letters flash.
- Change minute time using ▲ and ▼ buttons. (For most accurate time, set minute to *one minute past* current minute before proceeding to next step.)
- Press and hold SET button for 3 seconds when desired minute is as close as possible to zero seconds.
- Clock will stop flashing and will save settings.
- Press ▲ button to cycle through 5 brightness settings until reaching desired brightness.
- Built-in battery backup will retain all settings if there is a power failure or clock is unplugged and moved to a different location.

Need help? Email info@innOHvations.com