

XIXXIVVI

IXV

V

XL

X X I I I V I I I

ХХ

XXIVXLIXI

XVII

XXII

XΙ

х

х х 🗙

XL

X

Hours in white Minutes in red

CAREFULLY REMOVE PROTECTIVE PLASTIC COVERING FROM THE FRONT OF THE CLOCK.

XLVIIIXLI

Buttons Layout (on back panel)

SET (Setting Mode)

- ▲ Time adjust +
- ▼ Time adjust -

Setting Steps

- Insert AC adapter into back of clock and plug electric cord into wall outlet.
- Press and hold SET button for 5 seconds until white hour numbers flash.

X

- Change **hour** time using ▲ and ▼ buttons. Note: Hours are in 24-hour format -- XIII = 1:00PM; XXIV =12:00AM midnight.
- Press SET button briefly until <u>red</u> minute numbers flash.
- Change **minute** time using ▲ and ▼ buttons. (For most accurate time, set minute to *one minute* <u>past</u> current minute before proceeding to next step.)
- Press and hold SET button for 5 seconds when desired minute is as close as possible to zero seconds.
- Clock will stop flashing and will save settings.
- Built-in battery backup will retain all settings if there is a power failure or clock is unplugged and moved to a different location.

Need help? Email info@innOHvations.com